

# FALSE SIGNAL DISMISSAL



If the camera is in the buffering mode and a signal event occurs, the camera will begin recording

# FALSE SIGNAL DISMISSAL



**Press Select to Cancel**  
message will display for 10  
seconds


# FALSE SIGNAL DISMISSAL



Press the Select button, the signal activation will be reported false, the camera will end the recording, and return to buffering mode



# FALSE SIGNAL DISMISSAL



If the Select button is not pressed within 10 seconds, the message is removed, and the camera will continue recording